

Michel César

Bathroom Collection

FITTING OF BRACKETS SUPPLIED WITH LIGHT, NICO, CUBO, PIKO BATHROOM FURNITURE

1. Determine correct finished height of the top of the unit to suit your requirements. Normally we recommend 900mm overall from the floor. However ergonomically to establish the correct height, you stand bare footed with your palm of your hand flat on the bottom of the basin.
2. Now height is established, measure from top of unit including top or basin.
EG; Light cabinet 400mm plus 50mm top = 450mm.
Deduct this height from the desired height less the depth of the bracket supplied = 10mm
For example; Established finished height = 900mm
less height of unit & top = 450mm
less depth of bracket supplied = 10mm
Therefore bottom of bracket from floor = 440mm
3. Fix one bracket to solid fixing (short side 250mm wall) and fix additional bracket level with first bracket in solid fixing (ie; Studs etc). Brackets are for support only - please follow further instructions
4. Sit cabinet on brackets.
5. Fix cabinet through the top of the back to solid fixing in wall (screws not supplied).
6. Sit top on cabinet and fix to wall with fixing bolts supplied.

Note: We recommend the use of bottle traps to connect the waste for a tidier installation.

Thank you for purchasing this cabinet.

Best regards

Smail & Co

